



Alpha™ Trefoil or Single Cable Cleat

Installation Instructions

1) Remove the setscrew, sprung washer and nut. Fix the cleat to the support structure with a securing bolt, washer and nut (supplied upon request).



NOTE: The cleat may have the optional LSF (plastic base). Installation Instructions are common.



2) Install the cables.



NOTE: Trefoil installation pictured - Single installation similar.

3) Replace the setscrew, sprung washer and nut and tighten.



NOTE: Do not over-tighten. The cleat should secure the cable but does not need to be so tight that the cable bulges at either side of the cleat.



Range listed as follows: ALP01-AN0 to ALP15-AN0

Mounting orientation:
Horizontal or Vertical.

UL bolt torque values:

ALP-05-1N0: 26 lbf-in

Conduit & cable hardware 4CG8 with AH-2 & wet locations.

NOTE: UL tested bolt torque values may not represent the most ideal bolt torque setting for your cable, please see *.



THORNE &
DERRICK
INTERNATIONAL

Thorne & Derrick
+44 (0) 191 410 4292
www.powerandcables.com