

## **Installation Instructions Atlas Cleat**

1) Position the cable clamp and fixing (not supplied) onto the support structure.





**Single Cable** 



2) Install the cable.



3) Locate the other half of the cable clamp. Secure with a nut and washer (not supplied) to the support structure and tighten.





4) Important: Do not over tighten the cleat. The cleat should secure the cable but does not need to be so tight that the cable bulges at either side of the cleat.





WARNING - to prevent eddy currents and heating of the cleat the top tensioning bolt is made of stainless steel. Ensure that only this bolt is used and that bridging cannot take place.

Inst 30 - Atlas Cleat

Issue 05

23/08/11



Thorne & Derrick
DERRICK +44 (0) 191 410 4292
NTERNATIONAL www.powerandcables.com